



Typical Mounting Locations

These are typical mounting locations for best operation. Other mountings are possible. See Installation section for more information.


2-Throw Balance-Opposed Compressor




Pumping Unit




Engine and Vertical Shaft Pump




Y Type Reciprocating Compressor




Generator Sets



Cooling Tower Fan or Heat Exchanger



Engine Compressor



Turbine Centrifugal Compressor

